



Модель	A	B	C	D	E	F	G	H	I	J	Схема
TF-04-TN	26	14.5	18	12.5	5	6	10	14	M8	-	1
TF-05-TN	32	14.5	18	12.5	6	6	10	19	M8	-	1
TF-05-TA	26	14.5	15	9.5	5	6	10	14	M8	-	1
TF-05-TC	36.5	14.5	15	9.5	5	8.25	10	20	M8	12	3
TF-06-TN	36.5	17	22.5	15	8	7.5	12	20	M10	-	1
TF-06-TA	36.5	17	18.5	11	8	8.25	12	20	M10	-	1
TF-06-TB	36.5	17	18.5	11	8	6	12	14	M8	10	2
TF-06-TC	46.5	17	18.5	11	8	10.5	12	25	M10	14	3
TF-08-TN	48	20	25.5	16	8	11	14	25	M12	-	1
TF-08-TA	46.5	20	20.5	12	12	10.5	14	25	M12	-	1
TF-08-TB	46.5	20	20.5	12	12	8.25	14	20	M10	12	2
TF-08-TC	51	20	20.5	12	12	11	14	30	M16	16	3
TF-10-TN	55	22	25.5	16	8	11	16	30	M12	-	1
TF-10-TA	51	22	21.5	13	11	11	16	30	M12	-	1
TF-10-TB	51	22	21.5	13	11	10.5	16	25	M12	14	2
TF-10-TC	55.5	22	21.5	13	11	12	16	30	M12	21	3
TF-12-TA	55.5	29.5	27.75	16.25	13	12	21	30	M16	-	1
TF-12-TB	55.5	29.5	27.75	16.25	13	11	21	30	M12	16	2